



Adirondack Rocker Additional Assembly Instructions

Additional parts consist of:



- 2 each: Rockers
- 1 each: Additional hardware (includes 6 x 1 $\frac{3}{4}$ " stainless steel screws and 4 x 3" stainless steel screws)

NOTE: BOTH ROCKERS ARE LABELLED FOR CORRECT ALIGNMENT.

1. Turn assembled Adirondack upside down on a flat table top as shown.



2. Attach rockers to seat base legs. Insert three 1³/₄" screws through back of one seat base leg until tips show. Also insert two 3" screws through front of rocker until tips show. Apply glue and line up screws to pre-drilled holes on bottom of front leg and side of base leg. Tighten screws. Repeat for second rocker on other side.



3. Allow glue to dry and do any finishing sanding. Rocking chair is complete. Enjoy.

