



Garden Bench Assembly Instructions




Unpack and examine all parts, which consist of:

- 1 each: Bench back section
- 1 each: Bench seat section
- 1 each: Back support
- 2 each: Armrests
- 2 each: Legs and arm support sections
- 1 each: Instructions
- 1 each: Hardware kit (includes Titebond II adhesive, square drive bit and stainless screws).

NOTE: ALL PARTS ARE LABELLED FOR CORRECT POSITIONING

1. Attach legs and arm support sections to the bench seat section. Lay the seat section upside down on a table so the seat ends overhang the edge of the table. On the inside of one end of the seat base insert 7 No.8 x 1³/₄ " screws in the pre-drilled holes. Tighten one front and one back screw so that the screw tips just emerge from the outside of the seat base by about 3/16". This will allow you to be able to correctly line up the screws with the pre-drilled holes on the legs (see arrows on photos). Apply a bead of adhesive around the inside of the guide lines drawn on the outside of the seat base, position the appropriately labeled leg and arm support section so that the screws align with holes and tighten screws. Tighten the remaining five screws. Attach the second pair of legs and arm support in the same fashion on the opposite side of the seat section. Clean up any excess adhesive.





2. Attach the armrests to the leg arm supports. Turn the bench the right way up. Insert two screws through the underside of one armrest support until the screw tips protrude. Apply adhesive to the upper side of the arm support, align the screw holes on the armrest with the screws and tighten (the pencil outline on the underside of the armrest should aid in alignment). Repeat for the second armrest. Clean up any excess adhesive.



3. Attach the bench back section to the seat. Insert two screws through the pre-drilled outside holes in the base of the bench back section until the tips show. Apply adhesive to all three points of contact on seat and lift the back into position, taking care to align screws with holes. Tighten screws. Insert and tighten center screw. Clean up any excess adhesive.



4. Attach back support to armrests and back. Turn the bench upside down and rest it on its armrests. Insert 4 screws through the back support so the tips show. Apply adhesive, align the screw tips with the holes on the undersides of the armrests and tighten. Clean up any excess adhesive. Turn bench back on its feet. Whilst pulling the seat back towards the back support tighten the two No.8 x 3” screws through the back support into the seat back. Do any additional adhesive clean up and finished sanding that may be required (use 120 grit sandpaper) Enjoy!

